


HSA Approved Target Holders


4/22/01

Indoor Range



Use 1/2" round stock: wood; aluminum or steel. **NOTE:** Wood and aluminum don't withstand hits very well. Paper clip should be mounted on rear of holder using #8-32x3/4" machine screw and nut (may be recessed into shaft), through the .166" hole, using washer if necessary to hold the clip.

Outdoor Range



Use 1x3 common strapping for frame. Two 8' pieces are needed to building a Rifle Target Frame, three pieces for a Handgun Target Frame. Use two 1/4"x20x1 1/2" carriage bolts, washers and wing-nuts to fasten the legs, so that one frame may be used for either rifle or pistol shooting just by changing the legs. Fasten leftover pieces of 1x3 to strengthen the frame corners and legs and provide for a thicker bottom of leg. Cover surface with cardboard sheet stapled to frame. **NOTE:** Target frame may be made wider, if necessary.

Warning

These are the only authorized target holders allowed on the HSA outdoor range. Any other target or target holder must be approved, by the Board of Directors, for specific and restricted use. Loss of range privileges will result from the use of incorrect or improper targets or target holders.